



IMPORTANT INFORMATION PLEASE READ

WARNING: Swim Tether™ is NOT intended to be a lifesaving/oatation device

1. Swim Tether™ should be mounted no higher than 24" above the waterline for safety.
2. DO NOT Stand on the deck behind a Swim Tether™ that is in use.
3. Swim Tethers are intended for use in a swimming pool or swim spa. DO NOT use Swim Tether™ out of the water
4. The Swim Tether™ ber rod and aluminum connections are guaranteed against defects in materials and workmanship for life under it's intended use.
5. For proper use, enter the shallow end of the pool then secure to your waist.
6. DO NOT jump into a pool/swim spa while attached to the Swim Tether™.
7. REMOVE Swim Tether™ from deck plate and STORE when not in use.

NEVER let children use Swim Tether™ without adult supervision!

Care Instructions

1. Rinse Swim Tether™ with fresh water after every use.
2. Store in cool dry place
3. Inspect materials regularly for cracks, tears or other damage.
DO NOT use if damaged

WARNING: Read product safety information and instructions prior to use. Safety precautions should be taken in the use of all stretch cord products. Inspect product before each use. Product with cut, frayed, or otherwise damaged cords should not be used. Product with damaged or deformed hooks should not be used. Do not use on sharp or abrasive surfaces. Clips should be attached to allow the clip gates to fully close - do not attach the clips by the tip, or in any other manner that would not allow the gates to fully close. Eye protection should be worn during the use of this product. Stretch cord carefully, keeping body parts out of the path of possible rebound. Do not pull cords directly toward or away from yourself or other individual. Do not stretch cord more than 50% of its original length. Overstretching cord can cause hook or cord failure resulting in uncontrolled release. Uncontrolled release can cause severe injury to unprotected body parts, particularly eyes. Keep out of reach of children. Not to be used for climbing. MANUFACTURER IS NOT RESPONSIBLE FOR LOSS, INJURY OR DAMAGE DUE TO IMPORPER USE OF PRODUCT.

NEVER let Children use Swim Tether™ without adult supervision!